



## **COMMERCIAL & INDUSTRIAL SANITARY SERVICE REPAIR CHECKLIST**

### **PERMIT APPLICATION & SUBMITTAL REQUIREMENTS:**

- Complete an engineering permit application online by visiting our [Online Permitting Portal](#)
- Provide a copy of the signed contract
- Surety Bond and Certificate of Insurance are required for repair work in the Village right-of-way. See requirements [here](#).
- If repair is tributary to MWRD sewers submit a completed MWRD NRI form to the Village for review and signature by a Village representative.
  - Fill out all highlighted areas including Co-Permittee – Building owner’s contact information & signature in lower right-hand corner of permit.
    - For all sewer reconstruction, relining, rehabilitation, repair (including spot repairs involving excavation).
  - Contractor shall submit the fully executed NRI form and site plan to MWRD with associated permit fee.
- Submit site plan, plat of survey, or aerial photographs showing the following:
  - Location of existing sanitary sewer main.
  - Sanitary sewer service location, size, and material.
  - Location of the repair and a description of the proposed fix.
- Restoration:
  - All parkway areas shall be restored with four (4”) inches of topsoil and sod.
  - Private lawn areas shall be restored with four (4”) inches topsoil and seed.
  - [Concrete Aprons](#) – 8” PCC on 8” Aggregate 6”x6” #6 welded wire mesh.
  - [Concrete Sidewalk](#) – 5” PCC on 2” Aggregate.
  - HMA – 2” Binder on 2” Surface.
  - Street Repair – See [Pavement Open-Cut Repair detail](#)

### **INSPECTIONS:**

Inspections are scheduled by calling (847) 357-4220 between the hours of 8:00 a.m. and 5:00 p.m. Monday through Friday. Please have the **permit number** and **site address** ready. In addition, please allow a minimum of 24 hours when scheduling an inspection.

- Inspection of repair prior to backfill, note that the MWRD inspector shall be notified by the contractor.
- Aggregate base and framing as applicable for hardscape restoration
- Final